

GCulvert

Copyright © 2020 RCAD SOFTWARE SRL
e-mail: office@rcad.eu, rcad.software@gmail.com
site: <https://rcad.eu>

INSTALLATION

Always download the latest shareware version from <https://rcad.eu/gculvert/> (not from other websites)!

Set OFF "Create viewport for new layouts":

- in AutoCAD : Tools, Options, Display, Create Viewport in new layout, Off.
- in BricsCAD:
 CREATEVIEWPORTS, Off or
 Settings, "Viewports,layouts and tabs", "Automatic viewport creation", Off.

Enlarge the Text Window (press F2 in AutoCAD or BricsCAD and then drag the sides) almost to the size of the display. Otherwise, you will have to repeatedly press Enter during execution.

Follow these steps:

1) Unpack " GCulvert.zip " in the folder "C:\GCulvert"

The folder "C:\GCulvert" is mandatory!

2) in AutoCAD

- starting with Autocad 2014, set SECURELOAD variable to 0 or TRUSTEDPATHS to C:\GCulvert\Support

- launch the menu function:

Tools
Load Application
Startup Suite
Add
C:\GCulvert\Support\GCulvert.vlx

in BricsCAD

- launch the menu function (or use APPLOAD command):

Tools
Load Application
Add
C:\GCulvert\Support\GCulvert.des
Load

3) Open in AutoCAD "C:\GCulvert\Example\GCulvert example.dwg"

4) Type **GCU**; by clicking Help you will see the documentation

5) You can change different data

6) Press the OK button to run the program.

The shareware version (of trial) of the program has the limitations:

- run only 4 times,
- some quantities or dimensions are not displayed completely (the character '*' appears).